

## Special rinse aid

# B 150 OD

Neutral highly concentrated rinse aid for removing odours

### AREA OF APPLICATION:

- Suitable for professional glasswashing machines.
- Suitable for drinking glasses, including decorated.
- Permits proper draining the rinse water and so rapid, spotless drying of the glasses, avoiding odours.

For perfect cleaning results and optimum prevention of odours in glasses, we recommend using a Winterhalter glasswashing machine together with the special glasswashing detergent F 50 OD and a Winterhalter reverse osmosis unit.



### PRODUCT ADVANTAGES:

- Highly concentrated
- Outstanding glass wetting
- Very good draining
- Spotless drying
- Brilliant shine
- Particularly effectively prevents odours in glasses
- reserves beer foam stability

### DOSAGE:

With automatic dosing equipment, depending on the degree of soiling and the water quality. Having the rinse aid dosing set on-site by Winterhalter customer service assures perfect rinse aid results.

Water quality	Dosage in ml/l	°dH	[µS]	ppm CaCO <sub>3</sub>
Osmosis	<b>0.1-0.4</b>	0	0	0
Soft	<b>0.1-0.4</b>	0-8	0-240	0-142
Medium	<b>0.1-0.4</b>	8-14	240-420	142-249
Hard	<b>0.1-0.4</b>	> 14	> 420	> 249

### INGREDIENTS:

Non-ionic surfactants, phosphonates, polycarboxylates, alcohol, preservation agents, additives



# Technical data sheet

All-purpose rinse aid

# B 150 OD

## DELIVERY SIZES:

10 l	PE drum
------	---------

## TECHNICAL DATA:

Colour	colourless
Odour	product-specific
pH value	approx. 5 (concentrated)
Shelf life	24 months
Storage conditions	cool, dark, frost-free to max. 30 °C
Density	approx. 1.00 g/cm <sup>3</sup>

## SAFETY NOTES:

H319	Causes serious eye irritation.
P280	Wear protective gloves/protective clothing/eye protection/face protection.
P305+P351+P338	IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.
P337+P313	If eye irritation persists: Get medical advice/attention.
P501	Disposal in accordance with local regulations.

## DISPOSAL OF EMPTY PACKAGING:

- Completely emptied packaging is recyclable and can be disposed of by the end user through the DSD (Duales System Deutschland GmbH).
- Information on disposal of product residues can be found in the safety data sheet.

## IMPORTANT:

- Product is not intended for the general public. For commercial use only!
- Storage and transport permissible only in original packaging in upright position. Do not expose to direct sunlight. Protect from freezing.
- B 150 OD can be used in connection with all customary detergents for commercial dishwashing and glasswashing machines and is suitable for the food sector.
- Never mix with other products and do not transfer to other containers, bottles etc.!
- Colour variations in the product are caused by raw materials and storage and do not affect quality.
- The washing parameters should be kept in accordance with the DIN guidelines (DIN 10510 to 10512 and DIN 10522). Information of Working Party of Commercial Dishwashing should be kept in mind. In context refer to: [www.akggs.de](http://www.akggs.de)
- To ensure that your dishwasher functions durably and reliably, all filters should be cleaned at end of operation after the self-cleaning programme has ended. Leave the machine open slightly so the interior can dry and in order to build up corrosion protection.
- For cleaning and maintaining the stainless steel coverings of the machine we recommend Winterhalter C 122 grease solvent and C 162 stainless steel polish.
- You will find this product's safety data sheet, technical data sheet and sample operating instructions on our homepage at [www.winterhalter.biz](http://www.winterhalter.biz)